
60, 61, or 64 Series Channel Balance Generic Instructions


Below are generic instructions that may help you replace the 60, 61, or 64 series of channel balances. They may not match your window exactly.

Safety Guidelines

- Use help when working with a large window sash to avoid injury.
- Use caution! Maintain strong grip on balance when removing or installing. Balances are spring-loaded and they will tend to "shoot" upward possibly causing personal injury and/or product damage. Beware of oil causing slippery metal surface.



Push top of sash balance downward to dis-engage from tab or take-out clip. Then lift balance towards center of window 8 remove cord terminal clip from square hole located in center of frame jamb.



The advice offered herein should be reviewed and performed by a trained service provider. It is recommended that you consult with a competent and licensed construction contractor or building professional prior to taking any action. AMSCO - A Maintenance Supply Co, Inc. disclaims any and all liability associated with the use and/or provision of these instructions. Any reliance upon the information or advice is at the risk of the party so relying. The information contained herein may be changed from time to time without notification.